























Unit furniture PARTS LIST

ユニットファニチャー/0256A

<p>本体W900 01A1</p>  <p>W 960 D 550 H 1350</p>	<p>本体W1200 02A1</p>  <p>W 1260 D 550 H 1350</p>	<p>本体H2050 03A</p>  <p>W 1260 D 550 H 2050</p>	
<p>ハンガーパイプW900 0237A41E(パイプ) 0237A34D(ブラケット)</p>  <p>W 900</p>	<p>ハンガーパイプW1200 0243A49E(パイプ) 0237A34D(ブラケット)</p>  <p>W 1200</p>	<p>ストックボックス 0903Y208</p>  <p>W 900 D 440 H 400</p>	<p>ストックボックスW1200 0903Y209</p>  <p>W 1200 D 440 H 400</p>
<p>棚板W900 0903Y210</p>  <p>W 900 D 400 T 25</p>	<p>棚板W1200 0903Y211</p>  <p>W 1200 D 400 T 25</p>	<p>傾斜棚用コボレ止めW900 0243A81H</p>  <p>W 900</p>	<p>傾斜棚用コボレ止めW1200 0243A82H</p>  <p>W 1200</p>
<p>ステージW900 0903Y206</p>  <p>W 900 D 430 H 65</p>	<p>ステージW1200 0903Y207</p>  <p>W 1200 D 430 H 65</p>	<p>棚受け 0903Y223 (左右セット)</p>  <p>L 357</p>	<p>傾斜棚受け 0903Y224 (左右セット)</p>  <p>L 357</p>
<p>SバーW900 0237A44E(パイプ) 0237A33D(ブラケット) L50</p>  <p>W 900</p>	<p>SバーW1200 0243A50E(パイプ) 0237A35D(ブラケット) L70</p>  <p>W 1200</p>	<p>Sバー用フェイスハンガー 0243A46E</p>  <p>L 300</p>	<p>Sバー用傾斜ハンガー 0237A45E</p>  <p>L 300</p>
<p>ラインコンセント(棚下照明用) 0243A01P1</p>  <p>L 1170</p>	<p>棚下照明 0237A02P</p>  <p>W 780</p>	<p>ポードースポット 0256A01F1</p>  <p>W 1260 D 470 H 100</p>	<p>電源コードL=3000 0001V13P</p> 